

## Dräger Air Flow Tester Air Flow Indication

Air flow test tubes can be used universally: Simple and easy to use for the identification of air flows movements.



ST2046-2006

## Benefits

---

### Quick information

In many fields, such as mining or industry, it is very important to detect even the smallest air flows, in order to quickly and reliably evaluate the possible diffusion of dangerous substances. With the air flow test tubes, the source, direction and speed of the air flow are visible immediately.

---

### Simple to use

Smoking sulfuric acid is located in the tubes. When the top of the tube is opened, a small rubber ball is used to pump air through the tube. This creates visible white smoke, which is carried on any existing air flows.

---

### All-purpose

The air flow test tubes can be used until the "white smoke" has completely disappeared. If the test is completed before all the smoke disappears, the tube can be sealed again using the rubber cap provided.

## Ordering Information

**Dräger air flow test tubes**

Air flow test tubes	10	CH 25 301
Set of flow testers for air including 1 package of air flow test tubes, inflation bulb and rubber caps	1	CH 00 216
*Additional Dräger-Tubes upon request.		

## Notes

### CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA  
Moislinger Allee 53–55  
23558 Lübeck, Germany  
[www.draeger.com](http://www.draeger.com)

### Manufacturer:

Dräger Safety AG & Co. KGaA  
Revalstraße 1  
23560 Lübeck, Germany

### REGION EUROPE CENTRAL AND EUROPE NORTH

Dräger Safety AG & Co. KGaA  
Revalstraße 1  
23560 Lübeck, Germany  
Tel +49 451 882 0  
Fax +49 451 882 2080  
[info@draeger.com](mailto:info@draeger.com)

### REGION EUROPE SOUTH

Dräger Safety France SAS  
25, rue Georges Besse  
92182 Antony Cedex  
Tel +33 1 46 11 56 00  
Fax +33 1 40 96 97 20  
[europa.south@draeger.com](mailto:europa.south@draeger.com)

### REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA  
Branch Office  
P.O. Box 505108  
Dubai, United Arab Emirates  
Tel +971 4 4294 600  
Fax +971 4 4294 699  
[contactuae@draeger.com](mailto:contactuae@draeger.com)

### REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd  
25 International Business Park  
#04-20/21 German Centre  
Singapore 609916  
Tel +65 6308 9400  
Fax +65 6308 9401  
[asia.pacific@draeger.com](mailto:asia.pacific@draeger.com)

### REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.  
Complejo Business Park,  
V tower, 10th floor  
Panama City  
Tel +507 377 9100  
Fax +507 377 9130  
[contactcsa@draeger.com](mailto:contactcsa@draeger.com)

Locate your Regional  
Sales Representative at:  
[www.draeger.com/contact](http://www.draeger.com/contact)

